




SHOCKER[®] AMP



MAIN CHAMBER ASSEMBLY





SHOCKER[®] AMP


FIRING CAN ASSEMBLY





SHOCKER[®] AMP


SPOOL + SHUTTLE ASSEMBLY





SHOCKER[®] AMP


REAR CHAMBER ASSEMBLY





SHOCKER[®] AMP


FULL REGULATOR ASSEMBLY





SHOCKER[®] AMP


REGULATOR BASE ASSEMBLY





SHOCKER[®] AMP


REGULATOR PISTON ASSEMBLY





SHOCKER[®] AMP


REG SPRING BASE ASSEMBLY





SHOCKER[®] AMP

REG SPRNG GUIDE ASSEMBLY




SHK128



SHOCKER[®] AMP


SOLENOID VALVE ASSEMBLY





SHOCKER[®] AMP


SOLENOID MANIFOLD ASSEMBLY






SHOCKER[®] AMP

BOLT LATCH ASSEMBLY



SHK421



SSS014 (2x)



SHOCKER[®] AMP


GRIP FRAME ASSEMBLY





SHOCKER[®] AMP

FULL TRIGGER ASSEMBLY




ENSURE BEARING
OUTER RACE IS FLUSH
WITH BOTH OUTSIDE
SURFACES OF TRIGGER



SHOCKER[®] AMP

FULL ASA ASSEMBLY



SHK406
BOTTOM OF FRAME

FLT004


OM9007



SSC010 (2x)
BLUE LOCTITE 242



SHK437



SHK436




SHK138

OU9005
APPLY GR33SE™



SHOCKER[®] AMP

EYE COVER ASSEMBLY



SHK242

OB7M01
(1 x 1MM)

PIN011

SHK413 (RIGHT)
SHK412 (LEFT)

SPR036

SHK411

DO NOT GREASE!



SHOCKER®

AMP

FEEDNECK ASSEMBLY

